

CONTINUE FLOOD
SAFE CONSTRUCTION 2' ABOVE
FLOOD LEVEL.

REBAR THRU
STUDS

ALT. SIDING
ON 2x2's
12" OC LEAVES
CAVITY FOR
DRYING

BRICK &
MORTAR
INFILL LARGE
SMOOTH FOR

T-111 SIDING
TO FACILITATE
DRYING

PRESSURE TREATED 2x4
ON EDGE

TRIM WOOD HOLDING IN
GB PENSHIELD PANELS
(FOR EASY REMOVAL)

PENS SHIELD "GB" BOARD
(if getting a quality paint
job is problematic,
use cement wash w/
multi finish coats)

ADDITIONAL BLOCKING
BTW JOISTS & RIM
JOIST

6" RED WOOD BASE

2" FOAM INSULATION
FULLY ADHERE

3/8" x 1 1/2" SIL STRAPS

4' OC

